

Reversible Threaded Screw

Your PRO 523PX comes with a reversible 1/4"-20 / 3/8" screw. To switch sizes, unscrew the Center Column plate located at the top of the Center Column. Remove the threaded screw from the receptacle, turn upside-down and screw the Center Column plate back on the Center Column.



Short Center Column

Your Sunpak PRO 523PX tripod also comes with a Short Center Column for low angle use. To remove the standard Center Column, first loosen the Center Column Lock Knob and simply unscrew the accessory hook plate from the bottom of the Center Column, and remove it from the tripod body. Then install the Short Center Column for use.



SUNPAK LIMITED LIFETIME WARRANTY

This SUNPAK product has been carefully manufactured, accurately adjusted, inspected and thoroughly tested before shipment to assure you of the highest quality.

Should this SUNPAK product require service, we will repair or replace, at our option, any part or the product itself, which our examination shows to be defective in material or workmanship. This warranty does not apply to wear and tear associated with the normal use of the product. This warranty is non-transferable.

Repairs will be made to the product at no charge, under the terms of the warranty as stated above, only when accompanied by a dated and itemized bill of sale and nominal handling charge.

Be certain to follow all assembly and/or operating instructions with this product. This warranty is not valid if the product has been misused or damaged in any way that is beyond our control or through normal wear and tear associated with use. This warranty applies only to the product and we are not responsible in any way for losses, damages or any inconvenience caused by equipment failure.

Some states do not allow the exclusion or limitation of consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may have other rights which may vary from state to state.

Should service be required, the product should be carefully packed (in the original packaging if possible) and sent, prepaid and insured, along with a check or money order for \$15.95 (shipping and handling), to the address listed below. A note briefly describing the nature of the defect should also be enclosed to expedite handling.

Proof of purchase and payment for shipping and handling

SUNPAK® PRO 523PX

Operating Instructions

Congratulations on the purchase of your new SUNPAK tripod. Your tripod has been designed to be a sturdy, rugged, and dependable product and will provide you with many years of reliable service.

Please spend a few moments reviewing these instructions, so that you can take full advantage of your tripod's features and capabilities.



Precautions

- Insure that all handles, knobs and leg locks are properly tightened, and that all three legs are fully angled opened before use.
- **Do not** carry or transport the tripod with the camera equipment attached (as example but not limited to: over your shoulder or cradled in your arms).
- **Do not** Oil or Grease any part of the tripod.
- Do not use any solvents or thinners to clean your tripod. Use mild detergent and wipe dry with a soft, lint-free cloth only.
- **Do not** store or expose your tripod to excessive heat or cold or use close to any flame or fire.
- **Do not** exceed the load limit for this product.

OWNER'S RECORD

Please complete this section and retain with your original bill of sale for your records.

Purchase Date _____

Model _____

Dealer's Name _____

Address _____

City _____

State _____ Zip Code _____

ToCAD America Inc.

Sunpak Tripod Division
53 Green Pond Road
Rockaway, NJ 07866
973-627-9600
tocad.com

All Specifications Subject to Change without Notice.

Cat. no. 620-523-CFT-PX

PRO 523PX Specifications

Leg Sections	3
Leg Construction	Carbon Fiber
Maximum Height	63 in. (160 cm)
Minimum Height	9.85 in. (25 cm)
Folded Length	25 in. (63.5 cm)
Leg Diameter	.87 in. (2.2 cm)
Weight	4 lbs. (1.81 kg)
Load Capacity	6.1 lbs. (2.8 kg)

Tripod Components (See Picture A)

1. 3-Way Panhead
2. Pan and Tilt Handle
3. Vertical Tilt Handle
4. Quick Release Plate
5. Quick Release Lock Knob
6. Center Column Lock Knob
7. Leg Angle Adjustment Latch
8. Flip Leg Lock
9. Center Column
10. Retractable Accessory Hook
11. Rubber Feet
12. Short Center Column



Extending the Legs

Each leg of the PRO 523PX has separate leg extensions and each segment may be withdrawn as needed by using the flip lock leg locks. This permits setting your equipment at a comfortable height when positioning your tripod on uneven terrain. To secure, close the leg lock firmly in place. Not properly securing a leg lock may cause the tripod leg to retract and may cause damage to your tripod and camera.



Adjusting Leg Angle

To change the operation angle of any leg, fold the leg in slightly towards the center column, pull the Low angle Adjustment Latch until it locks. You can then spread the leg outward to its lowest angle, or fold the legs inward, which will lock the legs at greater angles, if desired.



Using the 3-Way Panhead

For panning and tilting, loosen the Pan and Tilt Handle, by turning the handle counterclockwise. Tilt the panhead as desired and retighten by turning clockwise or leave loose for panning. Utilize the Vertical Tilt Handle the same way for vertical use.



Quick Release Plate

To remove the Quick Release Plate, turn the Quick Release Lock Knob counterclockwise and slide the Quick Release Plate from the panhead.

Position the plate so that the camera mounting screw aligns with the matching receptacle on your camera or camcorder and attach, using the camera mounting screw. Slide the Quick Release Plate back into position. After doing so, secure the plate by turning the Quick Release Lock Knob clockwise until it locks.



Height Adjustments

Your Sunpak PRO 523PX tripod is equipped with a Lift-n-Lock Center Column for precise height adjustments.

To raise or lower the Center Column, loosen the Center Column Lock Knob. Grasp the tripod head and lift to the desired height. Retighten the Center Column Lock Knob to secure.

Note: Never release your camera until the Center Column Lock Knob is securely retightened.

